





Your GORE-TEX® garment is torn? Never mind!



When 2-layer laminates, intermediate liners and loose hanging liners have to be repaired, unstitch the lining of the garment at the hem to expose the white GORE-TEX® membrane. In case of 3-layer laminates, please seal directly on the textile backing of the GORE-TEX® fabric.



Repair the damaged spot of the laminated GORE-TEX® membrane with zig-zag stitching. Cut the repair patch to the appropriate size rounding off the corners. The patch should overlap the repair by 1 cm all around.



Place the patch with the adhesive side down on the white membrane side for 2-layer laminates, on the textile backing fabric for 3-layer laminates. Cover the repair set with the attached protective sheet, with the shiny side down on top of the patch. This will keep the iron clean.



Iron setting „cotton/linen“ (symbol: 3 dots). Press iron onto protective sheet with repair material below for 20 seconds. Remove protective sheet and rub off adhesive from the sheet before reuse. A slight overflow of adhesive at the patch edges indicates a successful sealing.